

Rain Wizard 50: Connector Kit Assembly Guide

Tools required(not included in the kit):

- Drill with 1/2" drill bit* (Any bit between 3/8" and 1/2" should work. Just be sure to leave 3/8" thickness to node walls)
- Flat head screwdriver

1) Position your Rain Wizards in the desired location and position



2) Locate the connector nodes on the backs of the barrels. Using a 3/16" drill bit, drill out holes in the nodes using the pilot hole as a guide. **Only drill the nodes you plan to use!**



3) Insert the pipe onto one of the drilled nodes



4) Slide metal clamps onto tube and connect other end to drilled node on other barrel



5) Slide clamps towards end of hose and strongly tighten using flat head screw driver



Reposition the barrels and you're done!

