


SENTINEL

HPH-4 & HPH-8 Main power connections



Always connect the main incoming power to the terminals shown above.

- 1) Bare or **green** ground wire connected to ground terminal
- 2) **Red** wire connected to one terminal on bottom of the relay.
- 3) **Black** wire connected to one terminal on bottom of the relay.
- 4) **White** wire is not used (cap off)

***Note :** DO NOT connect the main wires to the top side of the relay. Connecting the main power to the incorrect side of the relay will cause the lights to never shut off.